

# Kyocera® F-800 Toner Cartridge Unit



Oasis Imaging Products, Inc. Technical Support: (888) 627-6555

## Reference Information:

OEM PN: TK-6

OEM Yield: 4,000 pgs. (5% coverage)

## Printer Compatibility:

KYOCERA® F-800, F-800A

F-800T, F-820, F-850

## Instructions:

1. Lift the release lever on right side of printer and raise top cover (Fig. 1).
2. Insert new shutter (supplied with kit) between old toner unit and developer unit (Fig. 2).
3. Grasp the toner unit by the tab and slowly pull it out (simultaneously, the shutter will also come off Fig. 3).
4. Shake new toner cartridge horizontally 7-8 times. Rotate knob on cartridge one turn (Fig. 4).
5. Install new toner cartridge by fitting the top rail of the cartridge into the guide of the developer unit (see fig. 3). Continue by pulling off the plastic sealing strip from toner cartridge (Fig. 5).
6. Open the fuser cover and remove old wand. **CAUTION:** Fuser retains extreme heat and should be handled with caution.
7. Take new cleaning wand and use the rounded felt to clean the fuser roller (see Fig. 1). Install the new wand and close top of fuser assembly.
8. Press down the top of the printer and lock back into place.




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5